

PROFESSIONAL

BUR2 15E - 184316/185159; BUR2 18E - 184318/185161

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description		
	1	182672	Chuck screw	22	182694	Top insulation	
	2	182673	Chuck	23	182695	Battery power connector	
	3	182674	Torque setting ring	24	182696	Battery cell	
(1)	6	182677	Motor cover	25	182697	Bottom insulation	
(2)	6	182705	Motor cover	26	182698	Battery pack button	
(1)*	7	182678	Motor	27	182699	Bottom spring	
(1)**	7	185157	Motor	(1)	28	182700	Battery body
(2)*	7	182706	Motor	(2)	28	182707	Battery body
(2)**	7	185158	Motor	29	182701	Screws	
	8	182679	Interior wires	(1)	30	182702	Battery set BUR2 15E
	9	182680	Power indicator assembly	(2)	30	182708	Battery set BUR2 18E
	10	182681	Power indicator cover	(1)	31	182703	Charger EU
	11	182682	Switch	(1)	31	182704	Charger BS /UK type 230-240V/
	12	182683	Body power connector	(2)	31	182709	Charger EU BUR2 18E
	13	182684	Light pcb /led/	(2)	31	182710	Charger BS /UK type 230-240V/
	14	182685	Light cover	32	182714	Auxiliary handle	
*	15	182686	Left housing	*	33	182176	Reduktor set
**	15	185152	Left housing	**	33	185156	Reduktor set
*	16	182687	Gears selecting button	204	179860	Grease 2 - 1,00 kg.	
**	16	185172	Gears selecting button				
*	17	182688	Right housing				
**	17	185153	Right housing				
	18	182689	Reverse button				
	19	182691	Bit bracket				
	21	182693	Top of battery pack				

Note: *- till 01.04.2010; **- from 01.04.2010
 (1) - only for BUR2 15E; (2) - only for BUR2 18E

BUR2 15E BUR2 18E

